

Crystall-Ball

Default Factory Configuration



Default Factory Crystall-Ball Configuration

Bank	Set	Key	Message Type	Number	Channel	Mode	
1	1	1	CC	1	1	Crystall-Ball	.
1	1	2	CC	2	1	Crystall-Ball	.
1	1	3	CC	3	1	Crystall-Ball	.
1	1	4	CC	4	1	Crystall-Ball	.
1	1	5	CC	5	1	Crystall-Ball	.
1	1	6	No-Midi	.	.	Crystall-Ball	.
1	1	7	CC	7	1	Crystall-Ball	.
1	1	8	CC	8	1	Crystall-Ball	.
1	1	9	CC	9	1	Crystall-Ball	.
1	1	10	CC	10	1	Crystall-Ball	.
1	1	11	CC	11	1	Crystall-Ball	.
1	1	12	No-Midi	.	.	Crystall-Ball	.
1	1	13	CC	13	1	Crystall-Ball	.
1	1	14	CC	14	1	Crystall-Ball	.
1	1	15	CC	15	1	Crystall-Ball	.
1	1	16	CC	16	1	Crystall-Ball	.
1	1	17	CC	17	1	Crystall-Ball	.
1	1	18	No-Midi	.	.	Crystall-Ball	.
1	1	19	CC	19	1	Crystall-Ball	.
1	1	20	CC	20	1	Crystall-Ball	.
1	1	21	CC	21	1	Crystall-Ball	.
1	1	22	CC	22	1	Crystall-Ball	.
1	1	23	CC	23	1	Crystall-Ball	.
1	1	24	No-Midi	.	.	Crystall-Ball	.
1	2	1	Note	50	1	Crystall-Ball	.
1	2	2	Note	52	1	Crystall-Ball	.
1	2	3	Note	53	1	Crystall-Ball	.
1	2	4	Note	57	1	Crystall-Ball	.
1	2	5	Note	58	1	Crystall-Ball	.
1	2	6	No-Midi	.	.	Crystall-Ball	.
1	2	7	Note	62	1	Crystall-Ball	.
1	2	8	Note	64	1	Crystall-Ball	.
1	2	9	Note	65	1	Crystall-Ball	.
1	2	10	Note	69	1	Crystall-Ball	.
1	2	11	Note	70	1	Crystall-Ball	.
1	2	12	No-Midi	.	.	Crystall-Ball	.
1	2	13	Note	74	1	Crystall-Ball	.
1	2	14	Note	76	1	Crystall-Ball	.
1	2	15	Note	77	1	Crystall-Ball	.
1	2	16	Note	81	1	Crystall-Ball	.
1	2	17	Note	82	1	Crystall-Ball	.
1	2	18	No-Midi	.	.	Crystall-Ball	.
1	2	19	Note	86	1	Crystall-Ball	.
1	2	20	Note	88	1	Crystall-Ball	.
1	2	21	Note	89	1	Crystall-Ball	.
1	2	22	Note	93	1	Crystall-Ball	.
1	2	23	Note	94	1	Crystall-Ball	.
1	2	24	No-Midi	.	.	Crystall-Ball	.

Default Factory Crystall-Ball Configuration

Bank	Set	Key	Message Type	Number	Channel	Mode	
1	3	1	CC	24	1	Pad	Unlatch
1	3	2	CC	25	1	Pad	Unlatch
1	3	3	CC	26	1	Pad	Unlatch
1	3	4	CC	27	1	Pad	Unlatch
1	3	5	CC	28	1	Pad	Unlatch
1	3	6	CC	29	1	Pad	Unlatch
1	3	7	CC	30	1	Pad	Unlatch
1	3	8	CC	31	1	Pad	Unlatch
1	3	9	CC	32	1	Pad	Unlatch
1	3	10	CC	33	1	Pad	Unlatch
1	3	11	CC	34	1	Pad	Unlatch
1	3	12	CC	35	1	Pad	Unlatch
1	3	13	CC	36	1	Pad	Latch
1	3	14	CC	37	1	Pad	Latch
1	3	15	CC	38	1	Pad	Latch
1	3	16	CC	39	1	Pad	Latch
1	3	17	CC	40	1	Pad	Latch
1	3	18	CC	41	1	Pad	Latch
1	3	19	CC	42	1	Pad	Latch
1	3	20	CC	43	1	Pad	Latch
1	3	21	CC	44	1	Pad	Latch
1	3	22	CC	45	1	Pad	Latch
1	3	23	CC	46	1	Pad	Latch
1	3	24	CC	47	1	Pad	Latch
1	4	1	CC	1	1	Crystall-Ball	.
1	4	2	CC	2	1	Crystall-Ball	.
1	4	3	CC	3	1	Crystall-Ball	.
1	4	4	CC	4	1	Crystall-Ball	.
1	4	5	CC	5	1	Crystall-Ball	.
1	4	6	No-Midi	.	.	Crystall-Ball	.
1	4	7	Note	62	1	Crystall-Ball	.
1	4	8	Note	64	1	Crystall-Ball	.
1	4	9	Note	65	1	Crystall-Ball	.
1	4	10	Note	69	1	Crystall-Ball	.
1	4	11	Note	70	1	Crystall-Ball	.
1	4	12	No-Midi	.	.	Crystall-Ball	.
1	4	13	CC	24	1	Pad	Unlatch
1	4	14	CC	25	1	Pad	Unlatch
1	4	15	CC	26	1	Pad	Unlatch
1	4	16	CC	27	1	Pad	Unlatch
1	4	17	CC	28	1	Pad	Unlatch
1	4	18	CC	29	1	Pad	Unlatch
1	4	19	CC	36	1	Pad	Latch
1	4	20	CC	37	1	Pad	Latch
1	4	21	CC	38	1	Pad	Latch
1	4	22	CC	39	1	Pad	Latch
1	4	23	CC	40	1	Pad	Latch
1	4	24	CC	5	1	Pad	Latch

Default Factory Crystall-Ball Configuration

Bank	Set	Key	Message Type	Number	Channel	Mode	
1	5	1	CC	7	1	Crystall-Ball	.
1	5	2	CC	8	1	Crystall-Ball	.
1	5	3	CC	9	1	Crystall-Ball	.
1	5	4	CC	10	1	Crystall-Ball	.
1	5	5	CC	11	1	Crystall-Ball	.
1	5	6	No-Midi	.	.	Crystall-Ball	.
1	5	7	Note	74	1	Crystall-Ball	.
1	5	8	Note	76	1	Crystall-Ball	.
1	5	9	Note	77	1	Crystall-Ball	.
1	5	10	Note	81	1	Crystall-Ball	.
1	5	11	Note	82	1	Crystall-Ball	.
1	5	12	No-Midi	.	.	Crystall-Ball	.
1	5	13	CC	30	1	Pad	Unlatch
1	5	14	CC	31	1	Pad	Unlatch
1	5	15	CC	32	1	Pad	Unlatch
1	5	16	CC	33	1	Pad	Unlatch
1	5	17	CC	34	1	Pad	Unlatch
1	5	18	CC	35	1	Pad	Unlatch
1	5	19	CC	42	1	Pad	Latch
1	5	20	CC	43	1	Pad	Latch
1	5	21	CC	44	1	Pad	Latch
1	5	22	CC	45	1	Pad	Latch
1	5	23	CC	46	1	Pad	Latch
1	5	24	CC	47	1	Pad	Latch
2	1	1	CC	1	2	Crystall-Ball	.
2	1	2	CC	2	2	Crystall-Ball	.
2	1	3	CC	3	2	Crystall-Ball	.
2	1	4	CC	4	2	Crystall-Ball	.
2	1	5	CC	5	2	Crystall-Ball	.
2	1	6	No-Midi	.	.	Crystall-Ball	.
2	1	7	CC	7	2	Crystall-Ball	.
2	1	8	CC	8	2	Crystall-Ball	.
2	1	9	CC	9	2	Crystall-Ball	.
2	1	10	CC	10	2	Crystall-Ball	.
2	1	11	CC	11	2	Crystall-Ball	.
2	1	12	No-Midi	.	.	Crystall-Ball	.
2	1	13	CC	13	2	Crystall-Ball	.
2	1	14	CC	14	2	Crystall-Ball	.
2	1	15	CC	15	2	Crystall-Ball	.
2	1	16	CC	16	2	Crystall-Ball	.
2	1	17	CC	17	2	Crystall-Ball	.
2	1	18	No-Midi	.	.	Crystall-Ball	.
2	1	19	CC	19	2	Crystall-Ball	.
2	1	20	CC	20	2	Crystall-Ball	.
2	1	21	CC	21	2	Crystall-Ball	.
2	1	22	CC	22	2	Crystall-Ball	.
2	1	23	CC	23	2	Crystall-Ball	.
2	1	24	No-Midi	.	.	Crystall-Ball	.

Default Factory Crystall-Ball Configuration

Bank	Set	Key	Message Type	Number	Channel	Mode	
2	2	1	Note	50	2	Crystall-Ball	.
2	2	2	Note	52	2	Crystall-Ball	.
2	2	3	Note	53	2	Crystall-Ball	.
2	2	4	Note	57	2	Crystall-Ball	.
2	2	5	Note	58	2	Crystall-Ball	.
2	2	6	No-Midi	.	.	Crystall-Ball	.
2	2	7	Note	62	2	Crystall-Ball	.
2	2	8	Note	64	2	Crystall-Ball	.
2	2	9	Note	65	2	Crystall-Ball	.
2	2	10	Note	69	2	Crystall-Ball	.
2	2	11	Note	70	2	Crystall-Ball	.
2	2	12	No-Midi	.	.	Crystall-Ball	.
2	2	13	Note	74	2	Crystall-Ball	.
2	2	14	Note	76	2	Crystall-Ball	.
2	2	15	Note	77	2	Crystall-Ball	.
2	2	16	Note	81	2	Crystall-Ball	.
2	2	17	Note	82	2	Crystall-Ball	.
2	2	18	No-Midi	.	.	Crystall-Ball	.
2	2	19	Note	86	2	Crystall-Ball	.
2	2	20	Note	88	2	Crystall-Ball	.
2	2	21	Note	89	2	Crystall-Ball	.
2	2	22	Note	93	2	Crystall-Ball	.
2	2	23	Note	94	2	Crystall-Ball	.
2	2	24	No-Midi	.	.	Crystall-Ball	.
2	3	1	CC	24	2	Pad	Unlatch
2	3	2	CC	25	2	Pad	Unlatch
2	3	3	CC	26	2	Pad	Unlatch
2	3	4	CC	27	2	Pad	Unlatch
2	3	5	CC	28	2	Pad	Unlatch
2	3	6	CC	29	2	Pad	Unlatch
2	3	7	CC	30	2	Pad	Unlatch
2	3	8	CC	31	2	Pad	Unlatch
2	3	9	CC	32	2	Pad	Unlatch
2	3	10	CC	33	2	Pad	Unlatch
2	3	11	CC	34	2	Pad	Unlatch
2	3	12	CC	35	2	Pad	Unlatch
2	3	13	CC	36	2	Pad	Latch
2	3	14	CC	37	2	Pad	Latch
2	3	15	CC	38	2	Pad	Latch
2	3	16	CC	39	2	Pad	Latch
2	3	17	CC	40	2	Pad	Latch
2	3	18	CC	41	2	Pad	Latch
2	3	19	CC	42	2	Pad	Latch
2	3	20	CC	43	2	Pad	Latch
2	3	21	CC	44	2	Pad	Latch
2	3	22	CC	45	2	Pad	Latch
2	3	23	CC	46	2	Pad	Latch
2	3	24	CC	47	2	Pad	Latch

Default Factory Crystall-Ball Configuration

Bank	Set	Key	Message Type	Number	Channel	Mode	
2	4	1	CC	1	2	Crystall-Ball	.
2	4	2	CC	2	2	Crystall-Ball	.
2	4	3	CC	3	2	Crystall-Ball	.
2	4	4	CC	4	2	Crystall-Ball	.
2	4	5	CC	5	2	Crystall-Ball	.
2	4	6	No-Midi	.	.	Crystall-Ball	.
2	4	7	Note	62	2	Crystall-Ball	.
2	4	8	Note	64	2	Crystall-Ball	.
2	4	9	Note	65	2	Crystall-Ball	.
2	4	10	Note	69	2	Crystall-Ball	.
2	4	11	Note	70	2	Crystall-Ball	.
2	4	12	No-Midi	.	.	Crystall-Ball	.
2	4	13	CC	24	2	Pad	Unlatch
2	4	14	CC	25	2	Pad	Unlatch
2	4	15	CC	26	2	Pad	Unlatch
2	4	16	CC	27	2	Pad	Unlatch
2	4	17	CC	28	2	Pad	Unlatch
2	4	18	CC	29	2	Pad	Unlatch
2	4	19	CC	36	2	Pad	Latch
2	4	20	CC	37	2	Pad	Latch
2	4	21	CC	38	2	Pad	Latch
2	4	22	CC	39	2	Pad	Latch
2	4	23	CC	40	2	Pad	Latch
2	4	24	CC	5	2	Pad	Latch
2	5	1	CC	7	2	Crystall-Ball	.
2	5	2	CC	8	2	Crystall-Ball	.
2	5	3	CC	9	2	Crystall-Ball	.
2	5	4	CC	10	2	Crystall-Ball	.
2	5	5	CC	11	2	Crystall-Ball	.
2	5	6	No-Midi	.	.	Crystall-Ball	.
2	5	7	Note	74	2	Crystall-Ball	.
2	5	8	Note	76	2	Crystall-Ball	.
2	5	9	Note	77	2	Crystall-Ball	.
2	5	10	Note	81	2	Crystall-Ball	.
2	5	11	Note	82	2	Crystall-Ball	.
2	5	12	No-Midi	.	.	Crystall-Ball	.
2	5	13	CC	30	2	Pad	Unlatch
2	5	14	CC	31	2	Pad	Unlatch
2	5	15	CC	32	2	Pad	Unlatch
2	5	16	CC	33	2	Pad	Unlatch
2	5	17	CC	34	2	Pad	Unlatch
2	5	18	CC	35	2	Pad	Unlatch
2	5	19	CC	42	2	Pad	Latch
2	5	20	CC	43	2	Pad	Latch
2	5	21	CC	44	2	Pad	Latch
2	5	22	CC	45	2	Pad	Latch
2	5	23	CC	46	2	Pad	Latch
2	5	24	CC	47	2	Pad	Latch

Default Factory Crystall-Ball Configuration

Bank	Set	Key	Message Type	Number	Channel	Mode	
3	1	1	CC	1	3	Crystall-Ball	.
3	1	2	CC	2	3	Crystall-Ball	.
3	1	3	CC	3	3	Crystall-Ball	.
3	1	4	CC	4	3	Crystall-Ball	.
3	1	5	CC	5	3	Crystall-Ball	.
3	1	6	No-Midi	.	.	Crystall-Ball	.
3	1	7	CC	7	3	Crystall-Ball	.
3	1	8	CC	8	3	Crystall-Ball	.
3	1	9	CC	9	3	Crystall-Ball	.
3	1	10	CC	10	3	Crystall-Ball	.
3	1	11	CC	11	3	Crystall-Ball	.
3	1	12	No-Midi	.	.	Crystall-Ball	.
3	1	13	CC	13	3	Crystall-Ball	.
3	1	14	CC	14	3	Crystall-Ball	.
3	1	15	CC	15	3	Crystall-Ball	.
3	1	16	CC	16	3	Crystall-Ball	.
3	1	17	CC	17	3	Crystall-Ball	.
3	1	18	No-Midi	.	.	Crystall-Ball	.
3	1	19	CC	19	3	Crystall-Ball	.
3	1	20	CC	20	3	Crystall-Ball	.
3	1	21	CC	21	3	Crystall-Ball	.
3	1	22	CC	22	3	Crystall-Ball	.
3	1	23	CC	23	3	Crystall-Ball	.
3	1	24	No-Midi	.	.	Crystall-Ball	.
3	2	1	Note	50	3	Crystall-Ball	.
3	2	2	Note	52	3	Crystall-Ball	.
3	2	3	Note	53	3	Crystall-Ball	.
3	2	4	Note	57	3	Crystall-Ball	.
3	2	5	Note	58	3	Crystall-Ball	.
3	2	6	No-Midi	.	.	Crystall-Ball	.
3	2	7	Note	62	3	Crystall-Ball	.
3	2	8	Note	64	3	Crystall-Ball	.
3	2	9	Note	65	3	Crystall-Ball	.
3	2	10	Note	69	3	Crystall-Ball	.
3	2	11	Note	70	3	Crystall-Ball	.
3	2	12	No-Midi	.	.	Crystall-Ball	.
3	2	13	Note	74	3	Crystall-Ball	.
3	2	14	Note	76	3	Crystall-Ball	.
3	2	15	Note	77	3	Crystall-Ball	.
3	2	16	Note	81	3	Crystall-Ball	.
3	2	17	Note	82	3	Crystall-Ball	.
3	2	18	No-Midi	.	.	Crystall-Ball	.
3	2	19	Note	86	3	Crystall-Ball	.
3	2	20	Note	88	3	Crystall-Ball	.
3	2	21	Note	89	3	Crystall-Ball	.
3	2	22	Note	93	3	Crystall-Ball	.
3	2	23	Note	94	3	Crystall-Ball	.
3	2	24	No-Midi	.	.	Crystall-Ball	.

Default Factory Crystall-Ball Configuration

Bank	Set	Key	Message Type	Number	Channel	Mode	
3	3	1	CC	24	3	Pad	Unlatch
3	3	2	CC	25	3	Pad	Unlatch
3	3	3	CC	26	3	Pad	Unlatch
3	3	4	CC	27	3	Pad	Unlatch
3	3	5	CC	28	3	Pad	Unlatch
3	3	6	CC	29	3	Pad	Unlatch
3	3	7	CC	30	3	Pad	Unlatch
3	3	8	CC	31	3	Pad	Unlatch
3	3	9	CC	32	3	Pad	Unlatch
3	3	10	CC	33	3	Pad	Unlatch
3	3	11	CC	34	3	Pad	Unlatch
3	3	12	CC	35	3	Pad	Unlatch
3	3	13	CC	36	3	Pad	Latch
3	3	14	CC	37	3	Pad	Latch
3	3	15	CC	38	3	Pad	Latch
3	3	16	CC	39	3	Pad	Latch
3	3	17	CC	40	3	Pad	Latch
3	3	18	CC	41	3	Pad	Latch
3	3	19	CC	42	3	Pad	Latch
3	3	20	CC	43	3	Pad	Latch
3	3	21	CC	44	3	Pad	Latch
3	3	22	CC	45	3	Pad	Latch
3	3	23	CC	46	3	Pad	Latch
3	3	24	CC	47	3	Pad	Latch
3	4	1	CC	1	3	Crystall-Ball	.
3	4	2	CC	2	3	Crystall-Ball	.
3	4	3	CC	3	3	Crystall-Ball	.
3	4	4	CC	4	3	Crystall-Ball	.
3	4	5	CC	5	3	Crystall-Ball	.
3	4	6	No-Midi	.	.	Crystall-Ball	.
3	4	7	Note	62	3	Crystall-Ball	.
3	4	8	Note	64	3	Crystall-Ball	.
3	4	9	Note	65	3	Crystall-Ball	.
3	4	10	Note	69	3	Crystall-Ball	.
3	4	11	Note	70	3	Crystall-Ball	.
3	4	12	No-Midi	.	.	Crystall-Ball	.
3	4	13	CC	24	3	Pad	Unlatch
3	4	14	CC	25	3	Pad	Unlatch
3	4	15	CC	26	3	Pad	Unlatch
3	4	16	CC	27	3	Pad	Unlatch
3	4	17	CC	28	3	Pad	Unlatch
3	4	18	CC	29	3	Pad	Unlatch
3	4	19	CC	36	3	Pad	Latch
3	4	20	CC	37	3	Pad	Latch
3	4	21	CC	38	3	Pad	Latch
3	4	22	CC	39	3	Pad	Latch
3	4	23	CC	40	3	Pad	Latch
3	4	24	CC	5	3	Pad	Latch

Default Factory Crystall-Ball Configuration

Bank	Set	Key	Message Type	Number	Channel	Mode	
3	5	1	CC	7	3	Crystall-Ball	.
3	5	2	CC	8	3	Crystall-Ball	.
3	5	3	CC	9	3	Crystall-Ball	.
3	5	4	CC	10	3	Crystall-Ball	.
3	5	5	CC	11	3	Crystall-Ball	.
3	5	6	No-Midi	.	.	Crystall-Ball	.
3	5	7	Note	74	3	Crystall-Ball	.
3	5	8	Note	76	3	Crystall-Ball	.
3	5	9	Note	77	3	Crystall-Ball	.
3	5	10	Note	81	3	Crystall-Ball	.
3	5	11	Note	82	3	Crystall-Ball	.
3	5	12	No-Midi	.	.	Crystall-Ball	.
3	5	13	CC	30	3	Pad	Unlatch
3	5	14	CC	31	3	Pad	Unlatch
3	5	15	CC	32	3	Pad	Unlatch
3	5	16	CC	33	3	Pad	Unlatch
3	5	17	CC	34	3	Pad	Unlatch
3	5	18	CC	35	3	Pad	Unlatch
3	5	19	CC	42	3	Pad	Latch
3	5	20	CC	43	3	Pad	Latch
3	5	21	CC	44	3	Pad	Latch
3	5	22	CC	45	3	Pad	Latch
3	5	23	CC	46	3	Pad	Latch
3	5	24	CC	47	3	Pad	Latch
4	1	1	CC	1	4	Crystall-Ball	.
4	1	2	CC	2	4	Crystall-Ball	.
4	1	3	CC	3	4	Crystall-Ball	.
4	1	4	CC	4	4	Crystall-Ball	.
4	1	5	CC	5	4	Crystall-Ball	.
4	1	6	No-Midi	.	.	Crystall-Ball	.
4	1	7	CC	7	4	Crystall-Ball	.
4	1	8	CC	8	4	Crystall-Ball	.
4	1	9	CC	9	4	Crystall-Ball	.
4	1	10	CC	10	4	Crystall-Ball	.
4	1	11	CC	11	4	Crystall-Ball	.
4	1	12	No-Midi	.	.	Crystall-Ball	.
4	1	13	CC	13	4	Crystall-Ball	.
4	1	14	CC	14	4	Crystall-Ball	.
4	1	15	CC	15	4	Crystall-Ball	.
4	1	16	CC	16	4	Crystall-Ball	.
4	1	17	CC	17	4	Crystall-Ball	.
4	1	18	No-Midi	.	.	Crystall-Ball	.
4	1	19	CC	19	4	Crystall-Ball	.
4	1	20	CC	20	4	Crystall-Ball	.
4	1	21	CC	21	4	Crystall-Ball	.
4	1	22	CC	22	4	Crystall-Ball	.
4	1	23	CC	23	4	Crystall-Ball	.
4	1	24	No-Midi	.	.	Crystall-Ball	.

Default Factory Crystall-Ball Configuration

Bank	Set	Key	Message Type	Number	Channel	Mode	
4	2	1	Note	50	4	Crystall-Ball	.
4	2	2	Note	52	4	Crystall-Ball	.
4	2	3	Note	53	4	Crystall-Ball	.
4	2	4	Note	57	4	Crystall-Ball	.
4	2	5	Note	58	4	Crystall-Ball	.
4	2	6	No-Midi	.	.	Crystall-Ball	.
4	2	7	Note	62	4	Crystall-Ball	.
4	2	8	Note	64	4	Crystall-Ball	.
4	2	9	Note	65	4	Crystall-Ball	.
4	2	10	Note	69	4	Crystall-Ball	.
4	2	11	Note	70	4	Crystall-Ball	.
4	2	12	No-Midi	.	.	Crystall-Ball	.
4	2	13	Note	74	4	Crystall-Ball	.
4	2	14	Note	76	4	Crystall-Ball	.
4	2	15	Note	77	4	Crystall-Ball	.
4	2	16	Note	81	4	Crystall-Ball	.
4	2	17	Note	82	4	Crystall-Ball	.
4	2	18	No-Midi	.	.	Crystall-Ball	.
4	2	19	Note	86	4	Crystall-Ball	.
4	2	20	Note	88	4	Crystall-Ball	.
4	2	21	Note	89	4	Crystall-Ball	.
4	2	22	Note	93	4	Crystall-Ball	.
4	2	23	Note	94	4	Crystall-Ball	.
4	2	24	No-Midi	.	.	Crystall-Ball	.
4	3	1	CC	24	4	Pad	Unlatch
4	3	2	CC	25	4	Pad	Unlatch
4	3	3	CC	26	4	Pad	Unlatch
4	3	4	CC	27	4	Pad	Unlatch
4	3	5	CC	28	4	Pad	Unlatch
4	3	6	CC	29	4	Pad	Unlatch
4	3	7	CC	30	4	Pad	Unlatch
4	3	8	CC	31	4	Pad	Unlatch
4	3	9	CC	32	4	Pad	Unlatch
4	3	10	CC	33	4	Pad	Unlatch
4	3	11	CC	34	4	Pad	Unlatch
4	3	12	CC	35	4	Pad	Unlatch
4	3	13	CC	36	4	Pad	Latch
4	3	14	CC	37	4	Pad	Latch
4	3	15	CC	38	4	Pad	Latch
4	3	16	CC	39	4	Pad	Latch
4	3	17	CC	40	4	Pad	Latch
4	3	18	CC	41	4	Pad	Latch
4	3	19	CC	42	4	Pad	Latch
4	3	20	CC	43	4	Pad	Latch
4	3	21	CC	44	4	Pad	Latch
4	3	22	CC	45	4	Pad	Latch
4	3	23	CC	46	4	Pad	Latch
4	3	24	CC	47	4	Pad	Latch

Default Factory Crystall-Ball Configuration

Bank	Set	Key	Message Type	Number	Channel	Mode	
4	4	1	CC	1	4	Crystall-Ball	.
4	4	2	CC	2	4	Crystall-Ball	.
4	4	3	CC	3	4	Crystall-Ball	.
4	4	4	CC	4	4	Crystall-Ball	.
4	4	5	CC	5	4	Crystall-Ball	.
4	4	6	No-Midi	.	.	Crystall-Ball	.
4	4	7	Note	62	4	Crystall-Ball	.
4	4	8	Note	64	4	Crystall-Ball	.
4	4	9	Note	65	4	Crystall-Ball	.
4	4	10	Note	69	4	Crystall-Ball	.
4	4	11	Note	70	4	Crystall-Ball	.
4	4	12	No-Midi	.	.	Crystall-Ball	.
4	4	13	CC	24	4	Pad	Unlatch
4	4	14	CC	25	4	Pad	Unlatch
4	4	15	CC	26	4	Pad	Unlatch
4	4	16	CC	27	4	Pad	Unlatch
4	4	17	CC	28	4	Pad	Unlatch
4	4	18	CC	29	4	Pad	Unlatch
4	4	19	CC	36	4	Pad	Latch
4	4	20	CC	37	4	Pad	Latch
4	4	21	CC	38	4	Pad	Latch
4	4	22	CC	39	4	Pad	Latch
4	4	23	CC	40	4	Pad	Latch
4	4	24	CC	5	4	Pad	Latch
4	5	1	CC	7	4	Crystall-Ball	.
4	5	2	CC	8	4	Crystall-Ball	.
4	5	3	CC	9	4	Crystall-Ball	.
4	5	4	CC	10	4	Crystall-Ball	.
4	5	5	CC	11	4	Crystall-Ball	.
4	5	6	No-Midi	.	.	Crystall-Ball	.
4	5	7	Note	74	4	Crystall-Ball	.
4	5	8	Note	76	4	Crystall-Ball	.
4	5	9	Note	77	4	Crystall-Ball	.
4	5	10	Note	81	4	Crystall-Ball	.
4	5	11	Note	82	4	Crystall-Ball	.
4	5	12	No-Midi	.	.	Crystall-Ball	.
4	5	13	CC	30	4	Pad	Unlatch
4	5	14	CC	31	4	Pad	Unlatch
4	5	15	CC	32	4	Pad	Unlatch
4	5	16	CC	33	4	Pad	Unlatch
4	5	17	CC	34	4	Pad	Unlatch
4	5	18	CC	35	4	Pad	Unlatch
4	5	19	CC	42	4	Pad	Latch
4	5	20	CC	43	4	Pad	Latch
4	5	21	CC	44	4	Pad	Latch
4	5	22	CC	45	4	Pad	Latch
4	5	23	CC	46	4	Pad	Latch
4	5	24	CC	47	4	Pad	Latch

Default Factory Crystall-Ball Configuration

Bank	Set	Key	Message Type	Number	Channel	Mode	
5	1	1	CC	1	5	Crystall-Ball	.
5	1	2	CC	2	5	Crystall-Ball	.
5	1	3	CC	3	5	Crystall-Ball	.
5	1	4	CC	4	5	Crystall-Ball	.
5	1	5	CC	5	5	Crystall-Ball	.
5	1	6	No-Midi	.	.	Crystall-Ball	.
5	1	7	CC	7	5	Crystall-Ball	.
5	1	8	CC	8	5	Crystall-Ball	.
5	1	9	CC	9	5	Crystall-Ball	.
5	1	10	CC	10	5	Crystall-Ball	.
5	1	11	CC	11	5	Crystall-Ball	.
5	1	12	No-Midi	.	.	Crystall-Ball	.
5	1	13	CC	13	5	Crystall-Ball	.
5	1	14	CC	14	5	Crystall-Ball	.
5	1	15	CC	15	5	Crystall-Ball	.
5	1	16	CC	16	5	Crystall-Ball	.
5	1	17	CC	17	5	Crystall-Ball	.
5	1	18	No-Midi	.	.	Crystall-Ball	.
5	1	19	CC	19	5	Crystall-Ball	.
5	1	20	CC	20	5	Crystall-Ball	.
5	1	21	CC	21	5	Crystall-Ball	.
5	1	22	CC	22	5	Crystall-Ball	.
5	1	23	CC	23	5	Crystall-Ball	.
5	1	24	No-Midi	.	.	Crystall-Ball	.
5	2	1	Note	50	5	Crystall-Ball	.
5	2	2	Note	52	5	Crystall-Ball	.
5	2	3	Note	53	5	Crystall-Ball	.
5	2	4	Note	57	5	Crystall-Ball	.
5	2	5	Note	58	5	Crystall-Ball	.
5	2	6	No-Midi	.	.	Crystall-Ball	.
5	2	7	Note	62	5	Crystall-Ball	.
5	2	8	Note	64	5	Crystall-Ball	.
5	2	9	Note	65	5	Crystall-Ball	.
5	2	10	Note	69	5	Crystall-Ball	.
5	2	11	Note	70	5	Crystall-Ball	.
5	2	12	No-Midi	.	.	Crystall-Ball	.
5	2	13	Note	74	5	Crystall-Ball	.
5	2	14	Note	76	5	Crystall-Ball	.
5	2	15	Note	77	5	Crystall-Ball	.
5	2	16	Note	81	5	Crystall-Ball	.
5	2	17	Note	82	5	Crystall-Ball	.
5	2	18	No-Midi	.	.	Crystall-Ball	.
5	2	19	Note	86	5	Crystall-Ball	.
5	2	20	Note	88	5	Crystall-Ball	.
5	2	21	Note	89	5	Crystall-Ball	.
5	2	22	Note	93	5	Crystall-Ball	.
5	2	23	Note	94	5	Crystall-Ball	.
5	2	24	No-Midi	.	.	Crystall-Ball	.

Default Factory Crystall-Ball Configuration

Bank	Set	Key	Message Type	Number	Channel	Mode	
5	3	1	CC	24	5	Pad	Unlatch
5	3	2	CC	25	5	Pad	Unlatch
5	3	3	CC	26	5	Pad	Unlatch
5	3	4	CC	27	5	Pad	Unlatch
5	3	5	CC	28	5	Pad	Unlatch
5	3	6	CC	29	5	Pad	Unlatch
5	3	7	CC	30	5	Pad	Unlatch
5	3	8	CC	31	5	Pad	Unlatch
5	3	9	CC	32	5	Pad	Unlatch
5	3	10	CC	33	5	Pad	Unlatch
5	3	11	CC	34	5	Pad	Unlatch
5	3	12	CC	35	5	Pad	Unlatch
5	3	13	CC	36	5	Pad	Latch
5	3	14	CC	37	5	Pad	Latch
5	3	15	CC	38	5	Pad	Latch
5	3	16	CC	39	5	Pad	Latch
5	3	17	CC	40	5	Pad	Latch
5	3	18	CC	41	5	Pad	Latch
5	3	19	CC	42	5	Pad	Latch
5	3	20	CC	43	5	Pad	Latch
5	3	21	CC	44	5	Pad	Latch
5	3	22	CC	45	5	Pad	Latch
5	3	23	CC	46	5	Pad	Latch
5	3	24	CC	47	5	Pad	Latch
5	4	1	CC	1	5	Crystall-Ball	.
5	4	2	CC	2	5	Crystall-Ball	.
5	4	3	CC	3	5	Crystall-Ball	.
5	4	4	CC	4	5	Crystall-Ball	.
5	4	5	CC	5	5	Crystall-Ball	.
5	4	6	No-Midi	.	.	Crystall-Ball	.
5	4	7	Note	62	5	Crystall-Ball	.
5	4	8	Note	64	5	Crystall-Ball	.
5	4	9	Note	65	5	Crystall-Ball	.
5	4	10	Note	69	5	Crystall-Ball	.
5	4	11	Note	70	5	Crystall-Ball	.
5	4	12	No-Midi	.	.	Crystall-Ball	.
5	4	13	CC	24	5	Pad	Unlatch
5	4	14	CC	25	5	Pad	Unlatch
5	4	15	CC	26	5	Pad	Unlatch
5	4	16	CC	27	5	Pad	Unlatch
5	4	17	CC	28	5	Pad	Unlatch
5	4	18	CC	29	5	Pad	Unlatch
5	4	19	CC	36	5	Pad	Latch
5	4	20	CC	37	5	Pad	Latch
5	4	21	CC	38	5	Pad	Latch
5	4	22	CC	39	5	Pad	Latch
5	4	23	CC	40	5	Pad	Latch
5	4	24	CC	5	5	Pad	Latch

Default Factory Crystall-Ball Configuration

Bank	Set	Key	Message Type	Number	Channel	Mode	
5	5	1	CC	7	5	Crystall-Ball	.
5	5	2	CC	8	5	Crystall-Ball	.
5	5	3	CC	9	5	Crystall-Ball	.
5	5	4	CC	10	5	Crystall-Ball	.
5	5	5	CC	11	5	Crystall-Ball	.
5	5	6	No-Midi	.	.	Crystall-Ball	.
5	5	7	Note	74	5	Crystall-Ball	.
5	5	8	Note	76	5	Crystall-Ball	.
5	5	9	Note	77	5	Crystall-Ball	.
5	5	10	Note	81	5	Crystall-Ball	.
5	5	11	Note	82	5	Crystall-Ball	.
5	5	12	No-Midi	.	.	Crystall-Ball	.
5	5	13	CC	30	5	Pad	Unlatch
5	5	14	CC	31	5	Pad	Unlatch
5	5	15	CC	32	5	Pad	Unlatch
5	5	16	CC	33	5	Pad	Unlatch
5	5	17	CC	34	5	Pad	Unlatch
5	5	18	CC	35	5	Pad	Unlatch
5	5	19	CC	42	5	Pad	Latch
5	5	20	CC	43	5	Pad	Latch
5	5	21	CC	44	5	Pad	Latch
5	5	22	CC	45	5	Pad	Latch
5	5	23	CC	46	5	Pad	Latch
5	5	24	CC	47	5	Pad	Latch
6	1	1	CC	1	6	Crystall-Ball	.
6	1	2	CC	2	6	Crystall-Ball	.
6	1	3	CC	3	6	Crystall-Ball	.
6	1	4	CC	4	6	Crystall-Ball	.
6	1	5	CC	5	6	Crystall-Ball	.
6	1	6	No-Midi	.	.	Crystall-Ball	.
6	1	7	CC	7	6	Crystall-Ball	.
6	1	8	CC	8	6	Crystall-Ball	.
6	1	9	CC	9	6	Crystall-Ball	.
6	1	10	CC	10	6	Crystall-Ball	.
6	1	11	CC	11	6	Crystall-Ball	.
6	1	12	No-Midi	.	.	Crystall-Ball	.
6	1	13	CC	13	6	Crystall-Ball	.
6	1	14	CC	14	6	Crystall-Ball	.
6	1	15	CC	15	6	Crystall-Ball	.
6	1	16	CC	16	6	Crystall-Ball	.
6	1	17	CC	17	6	Crystall-Ball	.
6	1	18	No-Midi	.	.	Crystall-Ball	.
6	1	19	CC	19	6	Crystall-Ball	.
6	1	20	CC	20	6	Crystall-Ball	.
6	1	21	CC	21	6	Crystall-Ball	.
6	1	22	CC	22	6	Crystall-Ball	.
6	1	23	CC	23	6	Crystall-Ball	.
6	1	24	No-Midi	.	.	Crystall-Ball	.

Default Factory Crystall-Ball Configuration

Bank	Set	Key	Message Type	Number	Channel	Mode	
6	2	1	Note	50	6	Crystall-Ball	.
6	2	2	Note	52	6	Crystall-Ball	.
6	2	3	Note	53	6	Crystall-Ball	.
6	2	4	Note	57	6	Crystall-Ball	.
6	2	5	Note	58	6	Crystall-Ball	.
6	2	6	No-Midi	.	.	Crystall-Ball	.
6	2	7	Note	62	6	Crystall-Ball	.
6	2	8	Note	64	6	Crystall-Ball	.
6	2	9	Note	65	6	Crystall-Ball	.
6	2	10	Note	69	6	Crystall-Ball	.
6	2	11	Note	70	6	Crystall-Ball	.
6	2	12	No-Midi	.	.	Crystall-Ball	.
6	2	13	Note	74	6	Crystall-Ball	.
6	2	14	Note	76	6	Crystall-Ball	.
6	2	15	Note	77	6	Crystall-Ball	.
6	2	16	Note	81	6	Crystall-Ball	.
6	2	17	Note	82	6	Crystall-Ball	.
6	2	18	No-Midi	.	.	Crystall-Ball	.
6	2	19	Note	86	6	Crystall-Ball	.
6	2	20	Note	88	6	Crystall-Ball	.
6	2	21	Note	89	6	Crystall-Ball	.
6	2	22	Note	93	6	Crystall-Ball	.
6	2	23	Note	94	6	Crystall-Ball	.
6	2	24	No-Midi	.	.	Crystall-Ball	.
6	3	1	CC	24	6	Pad	Unlatch
6	3	2	CC	25	6	Pad	Unlatch
6	3	3	CC	26	6	Pad	Unlatch
6	3	4	CC	27	6	Pad	Unlatch
6	3	5	CC	28	6	Pad	Unlatch
6	3	6	CC	29	6	Pad	Unlatch
6	3	7	CC	30	6	Pad	Unlatch
6	3	8	CC	31	6	Pad	Unlatch
6	3	9	CC	32	6	Pad	Unlatch
6	3	10	CC	33	6	Pad	Unlatch
6	3	11	CC	34	6	Pad	Unlatch
6	3	12	CC	35	6	Pad	Unlatch
6	3	13	CC	36	6	Pad	Latch
6	3	14	CC	37	6	Pad	Latch
6	3	15	CC	38	6	Pad	Latch
6	3	16	CC	39	6	Pad	Latch
6	3	17	CC	40	6	Pad	Latch
6	3	18	CC	41	6	Pad	Latch
6	3	19	CC	42	6	Pad	Latch
6	3	20	CC	43	6	Pad	Latch
6	3	21	CC	44	6	Pad	Latch
6	3	22	CC	45	6	Pad	Latch
6	3	23	CC	46	6	Pad	Latch
6	3	24	CC	47	6	Pad	Latch

Default Factory Crystall-Ball Configuration

Bank	Set	Key	Message Type	Number	Channel	Mode	
6	4	1	CC	1	6	Crystall-Ball	.
6	4	2	CC	2	6	Crystall-Ball	.
6	4	3	CC	3	6	Crystall-Ball	.
6	4	4	CC	4	6	Crystall-Ball	.
6	4	5	CC	5	6	Crystall-Ball	.
6	4	6	No-Midi	.	.	Crystall-Ball	.
6	4	7	Note	62	6	Crystall-Ball	.
6	4	8	Note	64	6	Crystall-Ball	.
6	4	9	Note	65	6	Crystall-Ball	.
6	4	10	Note	69	6	Crystall-Ball	.
6	4	11	Note	70	6	Crystall-Ball	.
6	4	12	No-Midi	.	.	Crystall-Ball	.
6	4	13	CC	24	6	Pad	Unlatch
6	4	14	CC	25	6	Pad	Unlatch
6	4	15	CC	26	6	Pad	Unlatch
6	4	16	CC	27	6	Pad	Unlatch
6	4	17	CC	28	6	Pad	Unlatch
6	4	18	CC	29	6	Pad	Unlatch
6	4	19	CC	36	6	Pad	Latch
6	4	20	CC	37	6	Pad	Latch
6	4	21	CC	38	6	Pad	Latch
6	4	22	CC	39	6	Pad	Latch
6	4	23	CC	40	6	Pad	Latch
6	4	24	CC	5	6	Pad	Latch
6	5	1	CC	7	6	Crystall-Ball	.
6	5	2	CC	8	6	Crystall-Ball	.
6	5	3	CC	9	6	Crystall-Ball	.
6	5	4	CC	10	6	Crystall-Ball	.
6	5	5	CC	11	6	Crystall-Ball	.
6	5	6	No-Midi	.	.	Crystall-Ball	.
6	5	7	Note	74	6	Crystall-Ball	.
6	5	8	Note	76	6	Crystall-Ball	.
6	5	9	Note	77	6	Crystall-Ball	.
6	5	10	Note	81	6	Crystall-Ball	.
6	5	11	Note	82	6	Crystall-Ball	.
6	5	12	No-Midi	.	.	Crystall-Ball	.
6	5	13	CC	30	6	Pad	Unlatch
6	5	14	CC	31	6	Pad	Unlatch
6	5	15	CC	32	6	Pad	Unlatch
6	5	16	CC	33	6	Pad	Unlatch
6	5	17	CC	34	6	Pad	Unlatch
6	5	18	CC	35	6	Pad	Unlatch
6	5	19	CC	42	6	Pad	Latch
6	5	20	CC	43	6	Pad	Latch
6	5	21	CC	44	6	Pad	Latch
6	5	22	CC	45	6	Pad	Latch
6	5	23	CC	46	6	Pad	Latch
6	5	24	CC	47	6	Pad	Latch

Default Factory Crystall-Ball Configuration

Bank	Set	Key	Message Type	Number	Channel	Mode	
7	1	1	CC	1	16	Pad	Unlatch
7	1	2	CC	2	16	Pad	Unlatch
7	1	3	CC	3	16	Pad	Unlatch
7	1	4	CC	4	16	Pad	Unlatch
7	1	5	CC	5	16	Pad	Unlatch
7	1	6	CC	6	16	Pad	Unlatch
7	1	7	CC	7	16	Pad	Unlatch
7	1	8	CC	8	16	Pad	Unlatch
7	1	9	CC	9	16	Pad	Unlatch
7	1	10	CC	10	16	Pad	Unlatch
7	1	11	CC	11	16	Pad	Unlatch
7	1	12	CC	12	16	Pad	Unlatch
7	1	13	CC	13	16	Pad	Unlatch
7	1	14	CC	14	16	Pad	Unlatch
7	1	15	CC	15	16	Pad	Unlatch
7	1	16	CC	16	16	Pad	Unlatch
7	1	17	CC	17	16	Pad	Unlatch
7	1	18	CC	18	16	Pad	Unlatch
7	1	19	CC	19	16	Pad	Unlatch
7	1	20	CC	20	16	Pad	Unlatch
7	1	21	Note	0	16	Pad	Unlatch
7	1	22	Note	1	16	Pad	Unlatch
7	1	23	Note	2	16	Pad	Unlatch
7	1	24	Note	3	16	Pad	Unlatch
7	2	1	Note	50	1	Crystall-Ball	.
7	2	2	Note	53	1	Crystall-Ball	.
7	2	3	Note	57	1	Crystall-Ball	.
7	2	4	Note	58	1	Crystall-Ball	.
7	2	5	Note	62	1	Crystall-Ball	.
7	2	6	No-Midi	.	.	Crystall-Ball	.
7	2	7	CC	0	1	Crystall-Ball	.
7	2	8	CC	1	1	Crystall-Ball	.
7	2	9	CC	2	1	Crystall-Ball	.
7	2	10	CC	3	1	Crystall-Ball	.
7	2	11	CC	4	1	Crystall-Ball	.
7	2	12	No-Midi	.	.	Crystall-Ball	.
7	2	13	CC	5	1	Crystall-Ball	.
7	2	14	CC	6	1	Crystall-Ball	.
7	2	15	CC	7	1	Crystall-Ball	.
7	2	16	CC	8	1	Crystall-Ball	.
7	2	17	CC	9	1	Crystall-Ball	.
7	2	18	No-Midi	.	.	Crystall-Ball	.
7	2	19	CC	21	16	Pad	Unlatch
7	2	20	CC	22	16	Pad	Unlatch
7	2	21	CC	23	16	Pad	Unlatch
7	2	22	CC	24	16	Pad	Unlatch
7	2	23	CC	25	16	Pad	Unlatch
7	2	24	CC	26	16	Pad	Unlatch

Default Factory Crystall-Ball Configuration

Bank	Set	Key	Message Type	Number	Channel	Mode	
7	3	1	Note	62	1	Crystall-Ball	.
7	3	2	Note	65	1	Crystall-Ball	.
7	3	3	Note	69	1	Crystall-Ball	.
7	3	4	Note	70	1	Crystall-Ball	.
7	3	5	Note	74	1	Crystall-Ball	.
7	3	6	No-Midi	.	.	Crystall-Ball	.
7	3	7	CC	10	1	Crystall-Ball	.
7	3	8	CC	11	1	Crystall-Ball	.
7	3	9	CC	12	1	Crystall-Ball	.
7	3	10	CC	13	1	Crystall-Ball	.
7	3	11	CC	14	1	Crystall-Ball	.
7	3	12	No-Midi	.	.	Crystall-Ball	.
7	3	13	CC	15	1	Crystall-Ball	.
7	3	14	CC	16	1	Crystall-Ball	.
7	3	15	CC	17	1	Crystall-Ball	.
7	3	16	CC	18	1	Crystall-Ball	.
7	3	17	CC	19	1	Crystall-Ball	.
7	3	18	No-Midi	.	.	Crystall-Ball	.
7	3	19	CC	21	16	Pad	Unlatch
7	3	20	CC	22	16	Pad	Unlatch
7	3	21	CC	23	16	Pad	Unlatch
7	3	22	CC	24	16	Pad	Unlatch
7	3	23	CC	25	16	Pad	Unlatch
7	3	24	CC	26	16	Pad	Unlatch
7	4	1	Note	50	2	Crystall-Ball	.
7	4	2	Note	53	2	Crystall-Ball	.
7	4	3	Note	57	2	Crystall-Ball	.
7	4	4	Note	58	2	Crystall-Ball	.
7	4	5	Note	62	2	Crystall-Ball	.
7	4	6	No-Midi	.	.	Crystall-Ball	.
7	4	7	CC	20	1	Crystall-Ball	.
7	4	8	CC	21	1	Crystall-Ball	.
7	4	9	CC	22	1	Crystall-Ball	.
7	4	10	CC	23	1	Crystall-Ball	.
7	4	11	CC	24	1	Crystall-Ball	.
7	4	12	No-Midi	.	.	Crystall-Ball	.
7	4	13	CC	25	1	Crystall-Ball	.
7	4	14	CC	26	1	Crystall-Ball	.
7	4	15	CC	27	1	Crystall-Ball	.
7	4	16	CC	28	1	Crystall-Ball	.
7	4	17	CC	29	1	Crystall-Ball	.
7	4	18	No-Midi	.	.	Crystall-Ball	.
7	4	19	CC	21	16	Pad	Unlatch
7	4	20	CC	22	16	Pad	Unlatch
7	4	21	CC	23	16	Pad	Unlatch
7	4	22	CC	24	16	Pad	Unlatch
7	4	23	CC	25	16	Pad	Unlatch
7	4	24	CC	26	16	Pad	Unlatch

Default Factory Crystall-Ball Configuration

Bank	Set	Key	Message Type	Number	Channel	Mode	
7	5	1	Note	62	2	Crystall-Ball	.
7	5	2	Note	65	2	Crystall-Ball	.
7	5	3	Note	69	2	Crystall-Ball	.
7	5	4	Note	70	2	Crystall-Ball	.
7	5	5	Note	74	2	Crystall-Ball	.
7	5	6	No-Midi	.	.	Crystall-Ball	.
7	5	7	CC	30	1	Crystall-Ball	.
7	5	8	CC	31	1	Crystall-Ball	.
7	5	9	CC	32	1	Crystall-Ball	.
7	5	10	CC	33	1	Crystall-Ball	.
7	5	11	CC	34	1	Crystall-Ball	.
7	5	12	No-Midi	.	.	Crystall-Ball	.
7	5	13	CC	35	1	Crystall-Ball	.
7	5	14	CC	36	1	Crystall-Ball	.
7	5	15	CC	37	1	Crystall-Ball	.
7	5	16	CC	38	1	Crystall-Ball	.
7	5	17	CC	39	1	Crystall-Ball	.
7	5	18	No-Midi	.	.	Crystall-Ball	.
7	5	19	CC	21	16	Pad	Unlatch
7	5	20	CC	22	16	Pad	Unlatch
7	5	21	CC	23	16	Pad	Unlatch
7	5	22	CC	24	16	Pad	Unlatch
7	5	23	CC	25	16	Pad	Unlatch
7	5	24	CC	26	16	Pad	Unlatch
8	1	1	CC	1	16	Pad	Unlatch
8	1	2	CC	2	16	Pad	Unlatch
8	1	3	CC	3	16	Pad	Unlatch
8	1	4	CC	4	16	Pad	Unlatch
8	1	5	CC	5	16	Pad	Unlatch
8	1	6	CC	6	16	Pad	Unlatch
8	1	7	CC	7	16	Pad	Unlatch
8	1	8	CC	8	16	Pad	Unlatch
8	1	9	CC	9	16	Pad	Unlatch
8	1	10	CC	10	16	Pad	Unlatch
8	1	11	CC	11	16	Pad	Unlatch
8	1	12	CC	12	16	Pad	Unlatch
8	1	13	CC	13	16	Pad	Unlatch
8	1	14	CC	14	16	Pad	Unlatch
8	1	15	CC	15	16	Pad	Unlatch
8	1	16	CC	16	16	Pad	Unlatch
8	1	17	CC	17	16	Pad	Unlatch
8	1	18	CC	18	16	Pad	Unlatch
8	1	19	CC	19	16	Pad	Unlatch
8	1	20	CC	20	16	Pad	Unlatch
8	1	21	Note	0	16	Pad	Unlatch
8	1	22	Note	1	16	Pad	Unlatch
8	1	23	Note	2	16	Pad	Unlatch
8	1	24	Note	3	16	Pad	Unlatch

Default Factory Crystall-Ball Configuration

Bank	Set	Key	Message Type	Number	Channel	Mode	
8	2	1	Note	50	3	Crystall-Ball	.
8	2	2	Note	53	3	Crystall-Ball	.
8	2	3	Note	57	3	Crystall-Ball	.
8	2	4	Note	58	3	Crystall-Ball	.
8	2	5	Note	62	3	Crystall-Ball	.
8	2	6	No-Midi	.	.	Crystall-Ball	.
8	2	7	CC	0	2	Crystall-Ball	.
8	2	8	CC	1	2	Crystall-Ball	.
8	2	9	CC	2	2	Crystall-Ball	.
8	2	10	CC	3	2	Crystall-Ball	.
8	2	11	CC	4	2	Crystall-Ball	.
8	2	12	No-Midi	.	.	Crystall-Ball	.
8	2	13	CC	5	2	Crystall-Ball	.
8	2	14	CC	6	2	Crystall-Ball	.
8	2	15	CC	7	2	Crystall-Ball	.
8	2	16	CC	8	2	Crystall-Ball	.
8	2	17	CC	9	2	Crystall-Ball	.
8	2	18	No-Midi	.	.	Crystall-Ball	.
8	2	19	CC	21	16	Pad	Unlatch
8	2	20	CC	22	16	Pad	Unlatch
8	2	21	CC	23	16	Pad	Unlatch
8	2	22	CC	24	16	Pad	Unlatch
8	2	23	CC	25	16	Pad	Unlatch
8	2	24	CC	26	16	Pad	Unlatch
8	3	1	Note	62	3	Crystall-Ball	.
8	3	2	Note	65	3	Crystall-Ball	.
8	3	3	Note	69	3	Crystall-Ball	.
8	3	4	Note	70	3	Crystall-Ball	.
8	3	5	Note	74	3	Crystall-Ball	.
8	3	6	No-Midi	.	.	Crystall-Ball	.
8	3	7	CC	10	2	Crystall-Ball	.
8	3	8	CC	11	2	Crystall-Ball	.
8	3	9	CC	12	2	Crystall-Ball	.
8	3	10	CC	13	2	Crystall-Ball	.
8	3	11	CC	14	2	Crystall-Ball	.
8	3	12	No-Midi	.	.	Crystall-Ball	.
8	3	13	CC	15	2	Crystall-Ball	.
8	3	14	CC	16	2	Crystall-Ball	.
8	3	15	CC	17	2	Crystall-Ball	.
8	3	16	CC	18	2	Crystall-Ball	.
8	3	17	CC	19	2	Crystall-Ball	.
8	3	18	No-Midi	.	.	Crystall-Ball	.
8	3	19	CC	21	16	Pad	Unlatch
8	3	20	CC	22	16	Pad	Unlatch
8	3	21	CC	23	16	Pad	Unlatch
8	3	22	CC	24	16	Pad	Unlatch
8	3	23	CC	25	16	Pad	Unlatch
8	3	24	CC	26	16	Pad	Unlatch

Default Factory Crystall-Ball Configuration

Bank	Set	Key	Message Type	Number	Channel	Mode	
8	4	1	Note	50	4	Crystall-Ball	.
8	4	2	Note	53	4	Crystall-Ball	.
8	4	3	Note	57	4	Crystall-Ball	.
8	4	4	Note	58	4	Crystall-Ball	.
8	4	5	Note	62	4	Crystall-Ball	.
8	4	6	No-Midi	.	.	Crystall-Ball	.
8	4	7	CC	20	2	Crystall-Ball	.
8	4	8	CC	21	2	Crystall-Ball	.
8	4	9	CC	22	2	Crystall-Ball	.
8	4	10	CC	23	2	Crystall-Ball	.
8	4	11	CC	24	2	Crystall-Ball	.
8	4	12	No-Midi	.	.	Crystall-Ball	.
8	4	13	CC	25	2	Crystall-Ball	.
8	4	14	CC	26	2	Crystall-Ball	.
8	4	15	CC	27	2	Crystall-Ball	.
8	4	16	CC	28	2	Crystall-Ball	.
8	4	17	CC	29	2	Crystall-Ball	.
8	4	18	No-Midi	.	.	Crystall-Ball	.
8	4	19	CC	21	16	Pad	Unlatch
8	4	20	CC	22	16	Pad	Unlatch
8	4	21	CC	23	16	Pad	Unlatch
8	4	22	CC	24	16	Pad	Unlatch
8	4	23	CC	25	16	Pad	Unlatch
8	4	24	CC	26	16	Pad	Unlatch
8	5	1	Note	62	4	Crystall-Ball	.
8	5	2	Note	65	4	Crystall-Ball	.
8	5	3	Note	69	4	Crystall-Ball	.
8	5	4	Note	70	4	Crystall-Ball	.
8	5	5	Note	74	4	Crystall-Ball	.
8	5	6	No-Midi	.	.	Crystall-Ball	.
8	5	7	CC	30	2	Crystall-Ball	.
8	5	8	CC	31	2	Crystall-Ball	.
8	5	9	CC	32	2	Crystall-Ball	.
8	5	10	CC	33	2	Crystall-Ball	.
8	5	11	CC	34	2	Crystall-Ball	.
8	5	12	No-Midi	.	.	Crystall-Ball	.
8	5	13	CC	35	2	Crystall-Ball	.
8	5	14	CC	36	2	Crystall-Ball	.
8	5	15	CC	37	2	Crystall-Ball	.
8	5	16	CC	38	2	Crystall-Ball	.
8	5	17	CC	39	2	Crystall-Ball	.
8	5	18	No-Midi	.	.	Crystall-Ball	.
8	5	19	CC	21	16	Pad	Unlatch
8	5	20	CC	22	16	Pad	Unlatch
8	5	21	CC	23	16	Pad	Unlatch
8	5	22	CC	24	16	Pad	Unlatch
8	5	23	CC	25	16	Pad	Unlatch
8	5	24	CC	26	16	Pad	Unlatch

Default Factory Crystall-Ball Configuration

Bank	Set	Key	Message Type	Number	Channel	Mode	
9	1	1	CC	1	16	Pad	Unlatch
9	1	2	CC	2	16	Pad	Unlatch
9	1	3	CC	3	16	Pad	Unlatch
9	1	4	CC	4	16	Pad	Unlatch
9	1	5	CC	5	16	Pad	Unlatch
9	1	6	CC	6	16	Pad	Unlatch
9	1	7	CC	7	16	Pad	Unlatch
9	1	8	CC	8	16	Pad	Unlatch
9	1	9	CC	9	16	Pad	Unlatch
9	1	10	CC	10	16	Pad	Unlatch
9	1	11	CC	11	16	Pad	Unlatch
9	1	12	CC	12	16	Pad	Unlatch
9	1	13	CC	13	16	Pad	Unlatch
9	1	14	CC	14	16	Pad	Unlatch
9	1	15	CC	15	16	Pad	Unlatch
9	1	16	CC	16	16	Pad	Unlatch
9	1	17	CC	17	16	Pad	Unlatch
9	1	18	CC	18	16	Pad	Unlatch
9	1	19	CC	19	16	Pad	Unlatch
9	1	20	CC	20	16	Pad	Unlatch
9	1	21	Note	0	16	Pad	Unlatch
9	1	22	Note	1	16	Pad	Unlatch
9	1	23	Note	2	16	Pad	Unlatch
9	1	24	Note	3	16	Pad	Unlatch
9	2	1	Note	50	5	Crystall-Ball	.
9	2	2	Note	53	5	Crystall-Ball	.
9	2	3	Note	57	5	Crystall-Ball	.
9	2	4	Note	58	5	Crystall-Ball	.
9	2	5	Note	62	5	Crystall-Ball	.
9	2	6	No-Midi	.	.	Crystall-Ball	.
9	2	7	CC	0	3	Crystall-Ball	.
9	2	8	CC	1	3	Crystall-Ball	.
9	2	9	CC	2	3	Crystall-Ball	.
9	2	10	CC	3	3	Crystall-Ball	.
9	2	11	CC	4	3	Crystall-Ball	.
9	2	12	No-Midi	.	.	Crystall-Ball	.
9	2	13	CC	5	3	Crystall-Ball	.
9	2	14	CC	6	3	Crystall-Ball	.
9	2	15	CC	7	3	Crystall-Ball	.
9	2	16	CC	8	3	Crystall-Ball	.
9	2	17	CC	9	3	Crystall-Ball	.
9	2	18	No-Midi	.	.	Crystall-Ball	.
9	2	19	CC	21	16	Pad	Unlatch
9	2	20	CC	22	16	Pad	Unlatch
9	2	21	CC	23	16	Pad	Unlatch
9	2	22	CC	24	16	Pad	Unlatch
9	2	23	CC	25	16	Pad	Unlatch
9	2	24	CC	26	16	Pad	Unlatch

Default Factory Crystall-Ball Configuration

Bank	Set	Key	Message Type	Number	Channel	Mode	
9	3	1	Note	62	5	Crystall-Ball	.
9	3	2	Note	65	5	Crystall-Ball	.
9	3	3	Note	69	5	Crystall-Ball	.
9	3	4	Note	70	5	Crystall-Ball	.
9	3	5	Note	74	5	Crystall-Ball	.
9	3	6	No-Midi	.	.	Crystall-Ball	.
9	3	7	CC	10	3	Crystall-Ball	.
9	3	8	CC	11	3	Crystall-Ball	.
9	3	9	CC	12	3	Crystall-Ball	.
9	3	10	CC	13	3	Crystall-Ball	.
9	3	11	CC	14	3	Crystall-Ball	.
9	3	12	No-Midi	.	.	Crystall-Ball	.
9	3	13	CC	15	3	Crystall-Ball	.
9	3	14	CC	16	3	Crystall-Ball	.
9	3	15	CC	17	3	Crystall-Ball	.
9	3	16	CC	18	3	Crystall-Ball	.
9	3	17	CC	19	3	Crystall-Ball	.
9	3	18	No-Midi	.	.	Crystall-Ball	.
9	3	19	CC	21	16	Pad	Unlatch
9	3	20	CC	22	16	Pad	Unlatch
9	3	21	CC	23	16	Pad	Unlatch
9	3	22	CC	24	16	Pad	Unlatch
9	3	23	CC	25	16	Pad	Unlatch
9	3	24	CC	26	16	Pad	Unlatch
9	4	1	Note	50	6	Crystall-Ball	.
9	4	2	Note	53	6	Crystall-Ball	.
9	4	3	Note	57	6	Crystall-Ball	.
9	4	4	Note	58	6	Crystall-Ball	.
9	4	5	Note	62	6	Crystall-Ball	.
9	4	6	No-Midi	.	.	Crystall-Ball	.
9	4	7	CC	20	3	Crystall-Ball	.
9	4	8	CC	21	3	Crystall-Ball	.
9	4	9	CC	22	3	Crystall-Ball	.
9	4	10	CC	23	3	Crystall-Ball	.
9	4	11	CC	24	3	Crystall-Ball	.
9	4	12	No-Midi	.	.	Crystall-Ball	.
9	4	13	CC	25	3	Crystall-Ball	.
9	4	14	CC	26	3	Crystall-Ball	.
9	4	15	CC	27	3	Crystall-Ball	.
9	4	16	CC	28	3	Crystall-Ball	.
9	4	17	CC	29	3	Crystall-Ball	.
9	4	18	No-Midi	.	.	Crystall-Ball	.
9	4	19	CC	21	16	Pad	Unlatch
9	4	20	CC	22	16	Pad	Unlatch
9	4	21	CC	23	16	Pad	Unlatch
9	4	22	CC	24	16	Pad	Unlatch
9	4	23	CC	25	16	Pad	Unlatch
9	4	24	CC	26	16	Pad	Unlatch

Default Factory Crystall-Ball Configuration

Bank	Set	Key	Message Type	Number	Channel	Mode	
9	5	1	Note	62	6	Crystall-Ball	.
9	5	2	Note	65	6	Crystall-Ball	.
9	5	3	Note	69	6	Crystall-Ball	.
9	5	4	Note	70	6	Crystall-Ball	.
9	5	5	Note	74	6	Crystall-Ball	.
9	5	6	No-Midi	.	.	Crystall-Ball	.
9	5	7	CC	30	3	Crystall-Ball	.
9	5	8	CC	31	3	Crystall-Ball	.
9	5	9	CC	32	3	Crystall-Ball	.
9	5	10	CC	33	3	Crystall-Ball	.
9	5	11	CC	34	3	Crystall-Ball	.
9	5	12	No-Midi	.	.	Crystall-Ball	.
9	5	13	CC	35	3	Crystall-Ball	.
9	5	14	CC	36	3	Crystall-Ball	.
9	5	15	CC	37	3	Crystall-Ball	.
9	5	16	CC	38	3	Crystall-Ball	.
9	5	17	CC	39	3	Crystall-Ball	.
9	5	18	No-Midi	.	.	Crystall-Ball	.
9	5	19	CC	21	16	Pad	Unlatch
9	5	20	CC	22	16	Pad	Unlatch
9	5	21	CC	23	16	Pad	Unlatch
9	5	22	CC	24	16	Pad	Unlatch
9	5	23	CC	25	16	Pad	Unlatch
9	5	24	CC	26	16	Pad	Unlatch
10	1	1	CC	1	16	Pad	Unlatch
10	1	2	CC	2	16	Pad	Unlatch
10	1	3	CC	3	16	Pad	Unlatch
10	1	4	CC	4	16	Pad	Unlatch
10	1	5	CC	5	16	Pad	Unlatch
10	1	6	CC	6	16	Pad	Unlatch
10	1	7	CC	7	16	Pad	Unlatch
10	1	8	CC	8	16	Pad	Unlatch
10	1	9	CC	9	16	Pad	Unlatch
10	1	10	CC	10	16	Pad	Unlatch
10	1	11	CC	11	16	Pad	Unlatch
10	1	12	CC	12	16	Pad	Unlatch
10	1	13	CC	13	16	Pad	Unlatch
10	1	14	CC	14	16	Pad	Unlatch
10	1	15	CC	15	16	Pad	Unlatch
10	1	16	CC	16	16	Pad	Unlatch
10	1	17	CC	17	16	Pad	Unlatch
10	1	18	CC	18	16	Pad	Unlatch
10	1	19	CC	19	16	Pad	Unlatch
10	1	20	CC	20	16	Pad	Unlatch
10	1	21	Note	0	16	Pad	Unlatch
10	1	22	Note	1	16	Pad	Unlatch
10	1	23	Note	2	16	Pad	Unlatch
10	1	24	Note	3	16	Pad	Unlatch

Default Factory Crystall-Ball Configuration

Bank	Set	Key	Message Type	Number	Channel	Mode	
10	2	1	Note	50	7	Crystall-Ball	.
10	2	2	Note	53	7	Crystall-Ball	.
10	2	3	Note	57	7	Crystall-Ball	.
10	2	4	Note	58	7	Crystall-Ball	.
10	2	5	Note	62	7	Crystall-Ball	.
10	2	6	No-Midi	.	.	Crystall-Ball	.
10	2	7	CC	0	4	Crystall-Ball	.
10	2	8	CC	1	4	Crystall-Ball	.
10	2	9	CC	2	4	Crystall-Ball	.
10	2	10	CC	3	4	Crystall-Ball	.
10	2	11	CC	4	4	Crystall-Ball	.
10	2	12	No-Midi	.	.	Crystall-Ball	.
10	2	13	CC	5	4	Crystall-Ball	.
10	2	14	CC	6	4	Crystall-Ball	.
10	2	15	CC	7	4	Crystall-Ball	.
10	2	16	CC	8	4	Crystall-Ball	.
10	2	17	CC	9	4	Crystall-Ball	.
10	2	18	No-Midi	.	.	Crystall-Ball	.
10	2	19	CC	21	16	Pad	Unlatch
10	2	20	CC	22	16	Pad	Unlatch
10	2	21	CC	23	16	Pad	Unlatch
10	2	22	CC	24	16	Pad	Unlatch
10	2	23	CC	25	16	Pad	Unlatch
10	2	24	CC	26	16	Pad	Unlatch
10	3	1	Note	62	7	Crystall-Ball	.
10	3	2	Note	65	7	Crystall-Ball	.
10	3	3	Note	69	7	Crystall-Ball	.
10	3	4	Note	70	7	Crystall-Ball	.
10	3	5	Note	74	7	Crystall-Ball	.
10	3	6	No-Midi	.	.	Crystall-Ball	.
10	3	7	CC	10	4	Crystall-Ball	.
10	3	8	CC	11	4	Crystall-Ball	.
10	3	9	CC	12	4	Crystall-Ball	.
10	3	10	CC	13	4	Crystall-Ball	.
10	3	11	CC	14	4	Crystall-Ball	.
10	3	12	No-Midi	.	.	Crystall-Ball	.
10	3	13	CC	15	4	Crystall-Ball	.
10	3	14	CC	16	4	Crystall-Ball	.
10	3	15	CC	17	4	Crystall-Ball	.
10	3	16	CC	18	4	Crystall-Ball	.
10	3	17	CC	19	4	Crystall-Ball	.
10	3	18	No-Midi	.	.	Crystall-Ball	.
10	3	19	CC	21	16	Pad	Unlatch
10	3	20	CC	22	16	Pad	Unlatch
10	3	21	CC	23	16	Pad	Unlatch
10	3	22	CC	24	16	Pad	Unlatch
10	3	23	CC	25	16	Pad	Unlatch
10	3	24	CC	26	16	Pad	Unlatch

Default Factory Crystall-Ball Configuration

Bank	Set	Key	Message Type	Number	Channel	Mode	
10	4	1	Note	50	8	Crystall-Ball	.
10	4	2	Note	53	8	Crystall-Ball	.
10	4	3	Note	57	8	Crystall-Ball	.
10	4	4	Note	58	8	Crystall-Ball	.
10	4	5	Note	62	8	Crystall-Ball	.
10	4	6	No-Midi	.	.	Crystall-Ball	.
10	4	7	CC	20	4	Crystall-Ball	.
10	4	8	CC	21	4	Crystall-Ball	.
10	4	9	CC	22	4	Crystall-Ball	.
10	4	10	CC	23	4	Crystall-Ball	.
10	4	11	CC	24	4	Crystall-Ball	.
10	4	12	No-Midi	.	.	Crystall-Ball	.
10	4	13	CC	25	4	Crystall-Ball	.
10	4	14	CC	26	4	Crystall-Ball	.
10	4	15	CC	27	4	Crystall-Ball	.
10	4	16	CC	28	4	Crystall-Ball	.
10	4	17	CC	29	4	Crystall-Ball	.
10	4	18	No-Midi	.	.	Crystall-Ball	.
10	4	19	CC	21	16	Pad	Unlatch
10	4	20	CC	22	16	Pad	Unlatch
10	4	21	CC	23	16	Pad	Unlatch
10	4	22	CC	24	16	Pad	Unlatch
10	4	23	CC	25	16	Pad	Unlatch
10	4	24	CC	26	16	Pad	Unlatch
10	5	1	Note	62	8	Crystall-Ball	.
10	5	2	Note	65	8	Crystall-Ball	.
10	5	3	Note	69	8	Crystall-Ball	.
10	5	4	Note	70	8	Crystall-Ball	.
10	5	5	Note	74	8	Crystall-Ball	.
10	5	6	No-Midi	.	.	Crystall-Ball	.
10	5	7	CC	30	4	Crystall-Ball	.
10	5	8	CC	31	4	Crystall-Ball	.
10	5	9	CC	32	4	Crystall-Ball	.
10	5	10	CC	33	4	Crystall-Ball	.
10	5	11	CC	34	4	Crystall-Ball	.
10	5	12	No-Midi	.	.	Crystall-Ball	.
10	5	13	CC	35	4	Crystall-Ball	.
10	5	14	CC	36	4	Crystall-Ball	.
10	5	15	CC	37	4	Crystall-Ball	.
10	5	16	CC	38	4	Crystall-Ball	.
10	5	17	CC	39	4	Crystall-Ball	.
10	5	18	No-Midi	.	.	Crystall-Ball	.
10	5	19	CC	21	16	Pad	Unlatch
10	5	20	CC	22	16	Pad	Unlatch
10	5	21	CC	23	16	Pad	Unlatch
10	5	22	CC	24	16	Pad	Unlatch
10	5	23	CC	25	16	Pad	Unlatch
10	5	24	CC	26	16	Pad	Unlatch

Default Factory Crystall-Ball Configuration

Bank	Set	Key	Message Type	Number	Channel	Mode	
11	1	1	CC	1	16	Pad	Unlatch
11	1	2	CC	2	16	Pad	Unlatch
11	1	3	CC	3	16	Pad	Unlatch
11	1	4	CC	4	16	Pad	Unlatch
11	1	5	CC	5	16	Pad	Unlatch
11	1	6	CC	6	16	Pad	Unlatch
11	1	7	CC	7	16	Pad	Unlatch
11	1	8	CC	8	16	Pad	Unlatch
11	1	9	CC	9	16	Pad	Unlatch
11	1	10	CC	10	16	Pad	Unlatch
11	1	11	CC	11	16	Pad	Unlatch
11	1	12	CC	12	16	Pad	Unlatch
11	1	13	CC	13	16	Pad	Unlatch
11	1	14	CC	14	16	Pad	Unlatch
11	1	15	CC	15	16	Pad	Unlatch
11	1	16	CC	16	16	Pad	Unlatch
11	1	17	CC	17	16	Pad	Unlatch
11	1	18	CC	18	16	Pad	Unlatch
11	1	19	CC	19	16	Pad	Unlatch
11	1	20	CC	20	16	Pad	Unlatch
11	1	21	Note	0	16	Pad	Unlatch
11	1	22	Note	1	16	Pad	Unlatch
11	1	23	Note	2	16	Pad	Unlatch
11	1	24	Note	3	16	Pad	Unlatch
11	2	1	Note	50	9	Crystall-Ball	.
11	2	2	Note	53	9	Crystall-Ball	.
11	2	3	Note	57	9	Crystall-Ball	.
11	2	4	Note	58	9	Crystall-Ball	.
11	2	5	Note	62	9	Crystall-Ball	.
11	2	6	No-Midi	.	.	Crystall-Ball	.
11	2	7	CC	0	5	Crystall-Ball	.
11	2	8	CC	1	5	Crystall-Ball	.
11	2	9	CC	2	5	Crystall-Ball	.
11	2	10	CC	3	5	Crystall-Ball	.
11	2	11	CC	4	5	Crystall-Ball	.
11	2	12	No-Midi	.	.	Crystall-Ball	.
11	2	13	CC	5	5	Crystall-Ball	.
11	2	14	CC	6	5	Crystall-Ball	.
11	2	15	CC	7	5	Crystall-Ball	.
11	2	16	CC	8	5	Crystall-Ball	.
11	2	17	CC	9	5	Crystall-Ball	.
11	2	18	No-Midi	.	.	Crystall-Ball	.
11	2	19	CC	21	16	Pad	Unlatch
11	2	20	CC	22	16	Pad	Unlatch
11	2	21	CC	23	16	Pad	Unlatch
11	2	22	CC	24	16	Pad	Unlatch
11	2	23	CC	25	16	Pad	Unlatch
11	2	24	CC	26	16	Pad	Unlatch

Default Factory Crystall-Ball Configuration

Bank	Set	Key	Message Type	Number	Channel	Mode	
11	3	1	Note	62	9	Crystall-Ball	.
11	3	2	Note	65	9	Crystall-Ball	.
11	3	3	Note	69	9	Crystall-Ball	.
11	3	4	Note	70	9	Crystall-Ball	.
11	3	5	Note	74	9	Crystall-Ball	.
11	3	6	No-Midi	.	.	Crystall-Ball	.
11	3	7	CC	10	5	Crystall-Ball	.
11	3	8	CC	11	5	Crystall-Ball	.
11	3	9	CC	12	5	Crystall-Ball	.
11	3	10	CC	13	5	Crystall-Ball	.
11	3	11	CC	14	5	Crystall-Ball	.
11	3	12	No-Midi	.	.	Crystall-Ball	.
11	3	13	CC	15	5	Crystall-Ball	.
11	3	14	CC	16	5	Crystall-Ball	.
11	3	15	CC	17	5	Crystall-Ball	.
11	3	16	CC	18	5	Crystall-Ball	.
11	3	17	CC	19	5	Crystall-Ball	.
11	3	18	No-Midi	.	.	Crystall-Ball	.
11	3	19	CC	21	16	Pad	Unlatch
11	3	20	CC	22	16	Pad	Unlatch
11	3	21	CC	23	16	Pad	Unlatch
11	3	22	CC	24	16	Pad	Unlatch
11	3	23	CC	25	16	Pad	Unlatch
11	3	24	CC	26	16	Pad	Unlatch
11	4	1	Note	50	10	Crystall-Ball	.
11	4	2	Note	53	10	Crystall-Ball	.
11	4	3	Note	57	10	Crystall-Ball	.
11	4	4	Note	58	10	Crystall-Ball	.
11	4	5	Note	62	10	Crystall-Ball	.
11	4	6	No-Midi	.	.	Crystall-Ball	.
11	4	7	CC	20	5	Crystall-Ball	.
11	4	8	CC	21	5	Crystall-Ball	.
11	4	9	CC	22	5	Crystall-Ball	.
11	4	10	CC	23	5	Crystall-Ball	.
11	4	11	CC	24	5	Crystall-Ball	.
11	4	12	No-Midi	.	.	Crystall-Ball	.
11	4	13	CC	25	5	Crystall-Ball	.
11	4	14	CC	26	5	Crystall-Ball	.
11	4	15	CC	27	5	Crystall-Ball	.
11	4	16	CC	28	5	Crystall-Ball	.
11	4	17	CC	29	5	Crystall-Ball	.
11	4	18	No-Midi	.	.	Crystall-Ball	.
11	4	19	CC	21	16	Pad	Unlatch
11	4	20	CC	22	16	Pad	Unlatch
11	4	21	CC	23	16	Pad	Unlatch
11	4	22	CC	24	16	Pad	Unlatch
11	4	23	CC	25	16	Pad	Unlatch
11	4	24	CC	26	16	Pad	Unlatch

Default Factory Crystall-Ball Configuration

Bank	Set	Key	Message Type	Number	Channel	Mode	
11	5	1	Note	62	10	Crystall-Ball	.
11	5	2	Note	65	10	Crystall-Ball	.
11	5	3	Note	69	10	Crystall-Ball	.
11	5	4	Note	70	10	Crystall-Ball	.
11	5	5	Note	74	10	Crystall-Ball	.
11	5	6	No-Midi	.	.	Crystall-Ball	.
11	5	7	CC	30	5	Crystall-Ball	.
11	5	8	CC	31	5	Crystall-Ball	.
11	5	9	CC	32	5	Crystall-Ball	.
11	5	10	CC	33	5	Crystall-Ball	.
11	5	11	CC	34	5	Crystall-Ball	.
11	5	12	No-Midi	.	.	Crystall-Ball	.
11	5	13	CC	35	5	Crystall-Ball	.
11	5	14	CC	36	5	Crystall-Ball	.
11	5	15	CC	37	5	Crystall-Ball	.
11	5	16	CC	38	5	Crystall-Ball	.
11	5	17	CC	39	5	Crystall-Ball	.
11	5	18	No-Midi	.	.	Crystall-Ball	.
11	5	19	CC	21	16	Pad	Unlatch
11	5	20	CC	22	16	Pad	Unlatch
11	5	21	CC	23	16	Pad	Unlatch
11	5	22	CC	24	16	Pad	Unlatch
11	5	23	CC	25	16	Pad	Unlatch
11	5	24	CC	26	16	Pad	Unlatch
12	1	1	CC	1	16	Pad	Unlatch
12	1	2	CC	2	16	Pad	Unlatch
12	1	3	CC	3	16	Pad	Unlatch
12	1	4	CC	4	16	Pad	Unlatch
12	1	5	CC	5	16	Pad	Unlatch
12	1	6	CC	6	16	Pad	Unlatch
12	1	7	CC	7	16	Pad	Unlatch
12	1	8	CC	8	16	Pad	Unlatch
12	1	9	CC	9	16	Pad	Unlatch
12	1	10	CC	10	16	Pad	Unlatch
12	1	11	CC	11	16	Pad	Unlatch
12	1	12	CC	12	16	Pad	Unlatch
12	1	13	CC	13	16	Pad	Unlatch
12	1	14	CC	14	16	Pad	Unlatch
12	1	15	CC	15	16	Pad	Unlatch
12	1	16	CC	16	16	Pad	Unlatch
12	1	17	CC	17	16	Pad	Unlatch
12	1	18	CC	18	16	Pad	Unlatch
12	1	19	CC	19	16	Pad	Unlatch
12	1	20	CC	20	16	Pad	Unlatch
12	1	21	Note	0	16	Pad	Unlatch
12	1	22	Note	1	16	Pad	Unlatch
12	1	23	Note	2	16	Pad	Unlatch
12	1	24	Note	3	16	Pad	Unlatch

Default Factory Crystall-Ball Configuration

Bank	Set	Key	Message Type	Number	Channel	Mode	
12	2	1	CC	27	16	Crystall-Ball	.
12	2	2	CC	28	16	Crystall-Ball	.
12	2	3	CC	29	16	Crystall-Ball	.
12	2	4	CC	30	16	Crystall-Ball	.
12	2	5	CC	31	16	Crystall-Ball	.
12	2	6	No-Midi	.	.	Crystall-Ball	.
12	2	7	CC	32	16	Crystall-Ball	.
12	2	8	CC	33	16	Crystall-Ball	.
12	2	9	CC	34	16	Crystall-Ball	.
12	2	10	CC	35	16	Crystall-Ball	.
12	2	11	CC	36	16	Crystall-Ball	.
12	2	12	No-Midi	.	.	Crystall-Ball	.
12	2	13	CC	37	16	Crystall-Ball	.
12	2	14	CC	38	16	Crystall-Ball	.
12	2	15	CC	39	16	Crystall-Ball	.
12	2	16	CC	40	16	Crystall-Ball	.
12	2	17	CC	41	16	Crystall-Ball	.
12	2	18	No-Midi	.	.	Crystall-Ball	.
12	2	19	CC	21	16	Pad	Unlatch
12	2	20	CC	22	16	Pad	Unlatch
12	2	21	CC	23	16	Pad	Unlatch
12	2	22	CC	24	16	Pad	Unlatch
12	2	23	CC	25	16	Pad	Unlatch
12	2	24	CC	26	16	Pad	Unlatch
12	3	1	CC	47	16	Crystall-Ball	.
12	3	2	CC	48	16	Crystall-Ball	.
12	3	3	CC	49	16	Crystall-Ball	.
12	3	4	CC	50	16	Crystall-Ball	.
12	3	5	CC	51	16	Crystall-Ball	.
12	3	6	No-Midi	.	.	Crystall-Ball	.
12	3	7	No-Midi	.	.	Crystall-Ball	.
12	3	8	CC	52	16	Crystall-Ball	.
12	3	9	CC	53	16	Crystall-Ball	.
12	3	10	CC	54	16	Crystall-Ball	.
12	3	11	No-Midi	.	.	Crystall-Ball	.
12	3	12	No-Midi	.	.	Crystall-Ball	.
12	3	13	CC	55	16	Pad	Unlatch
12	3	14	CC	56	16	Pad	Unlatch
12	3	15	CC	57	16	Pad	Unlatch
12	3	16	CC	58	16	Pad	Unlatch
12	3	17	CC	59	16	Pad	Unlatch
12	3	18	CC	60	16	Pad	Unlatch
12	3	19	CC	42	16	Pad	Unlatch
12	3	20	CC	43	16	Pad	Unlatch
12	3	21	CC	44	16	Pad	Unlatch
12	3	22	CC	45	16	Pad	Unlatch
12	3	23	CC	46	16	Pad	Unlatch
12	3	24	CC	87	16	Pad	Unlatch

Default Factory Crystall-Ball Configuration

Bank	Set	Key	Message Type	Number	Channel	Mode	
12	4	1	Note	48	16	Pad	Unlatch
12	4	2	Note	49	16	Pad	Unlatch
12	4	3	Note	50	16	Pad	Unlatch
12	4	4	Note	51	16	Pad	Unlatch
12	4	5	No-Midi	.	.	Pad	Unlatch
12	4	6	No-Midi	.	.	Pad	Unlatch
12	4	7	Note	44	16	Pad	Unlatch
12	4	8	Note	45	16	Pad	Unlatch
12	4	9	Note	46	16	Pad	Unlatch
12	4	10	Note	47	16	Pad	Unlatch
12	4	11	No-Midi	.	.	Pad	Unlatch
12	4	12	No-Midi	.	.	Pad	Unlatch
12	4	13	Note	40	16	Pad	Unlatch
12	4	14	Note	41	16	Pad	Unlatch
12	4	15	Note	42	16	Pad	Unlatch
12	4	16	Note	43	16	Pad	Unlatch
12	4	17	No-Midi	.	.	Pad	Unlatch
12	4	18	No-Midi	.	.	Pad	Unlatch
12	4	19	Note	36	16	Pad	Unlatch
12	4	20	Note	37	16	Pad	Unlatch
12	4	21	Note	38	16	Pad	Unlatch
12	4	22	Note	39	16	Pad	Unlatch
12	4	23	No-Midi	.	.	Pad	Unlatch
12	4	24	No-Midi	.	.	Pad	Unlatch
12	5	1	CC	66	16	Crystall-Ball	.
12	5	2	CC	67	16	Crystall-Ball	.
12	5	3	CC	68	16	Crystall-Ball	.
12	5	4	CC	69	16	Crystall-Ball	.
12	5	5	CC	70	16	Crystall-Ball	.
12	5	6	No-Midi	.	.	Crystall-Ball	.
12	5	7	CC	71	16	Crystall-Ball	.
12	5	8	CC	72	16	Crystall-Ball	.
12	5	9	CC	73	16	Crystall-Ball	.
12	5	10	CC	74	16	Crystall-Ball	.
12	5	11	CC	75	16	Crystall-Ball	.
12	5	12	No-Midi	.	.	Crystall-Ball	.
12	5	13	CC	61	16	Pad	Unlatch
12	5	14	CC	62	16	Pad	Unlatch
12	5	15	CC	63	16	Pad	Unlatch
12	5	16	CC	64	16	Pad	Unlatch
12	5	17	CC	65	16	Pad	Unlatch
12	5	18	No-Midi	.	.	Pad	Unlatch
12	5	19	CC	21	16	Pad	Unlatch
12	5	20	CC	22	16	Pad	Unlatch
12	5	21	CC	23	16	Pad	Unlatch
12	5	22	CC	24	16	Pad	Unlatch
12	5	23	CC	25	16	Pad	Unlatch
12	5	24	CC	26	16	Pad	Unlatch